

DLO | HomeDock™ for iPod

USER MANUAL

Getting Started	4
Connecting HomeDock	
Home Stereo	6
Home Theater (Stereo & TV)	7
Desktop PC or Mac	8
Powered Speakers	8
Playing Music	10
Viewing Photos	14
Using with PC or Mac	17
Troubleshooting & Support	18
Tech Specs	19
Warranty	20

© 2005 DIGITAL LIFESTYLE OUTFITTERS

HomeDock, Digital Lifestyle Outfitters and DLO logo are trademarks of Digital Lifestyle Outfitters.



iPod is a registered trademark of Apple Computer, Inc. All Rights Reserved

Printed in Taiwan

M99764-050824-B

What's Included

1. Dock
2. Clear Plastic Support Stand
3. Support Stand Adjustment Screw
4. Remote Control
5. Battery for Remote Control
6. AC adapter
7. AV Cable: RCA style L/R analog audio and video
8. Audio Cable: RCA style L/R analog audio to female mini



Assembling your DLO HomeDock

1. Remove the adjustment screw on top of the Base unit and slide the iPod Support Stand into the holder base.
NOTE: Be sure to line up the Support Stand's cutout slot with the adjustment screw on the HomeDock base.
2. To set your Support Stand to the desired depth, first plug your iPod into the HomeDock's 30-pin connector.
3. Slide the Support Stand toward the iPod until the iPod is gently resting against the Support Stand so that the back of the iPod is parallel with the back of the Stand.
4. Tighten the Support Stand's adjustment screw to secure the Stand in place. **Do not over-tighten the screw.**



Home Stereo

1. Plug the included AC power adapter into the back of the HomeDock base, then into any available AC power outlet.
2. Plug the included A/V Cable into the back of the HomeDock base. Be sure to match the color on the A/V plugs (red, white and yellow) with the corresponding jack color or input type.
3. Plug the other end of the A/V Cable into the corresponding jacks of any available input on your home stereo receiver - White plug is for Left audio, and Red plug is for Right audio. Any extra Tape Input or Aux Input on your home stereo will work fine.
NOTE: The Yellow plug is for Video. If your Receiver does not have Video input, just leave it unplugged.
4. Connect your iPod or iPod mini by carefully lowering it onto the iPod connector of the HomeDock so that it is resting against the Support Stand.
5. Using your HomeDock Remote Control, turn on the Power to your HomeDock. Also turn on your home stereo and select the correct input function.

6. Hit play on your HomeDock Remote Control and enjoy your iPod's music through your home stereo.

Home Theater (Stereo & TV)

1. Plug the included AC power adapter into the back of the HomeDock base, then into any available AC power outlet.
2. Plug the included A/V Cable into the back of the HomeDock base. Be sure to match the color on the A/V plugs (red, white and yellow) with the corresponding jack color or input type. If you have an S-Video connection available on your TV, use an S-Video cable (not included) for superior picture quality when viewing photos.
3. Plug the other end of the A/V Cable into the corresponding jacks on your home stereo receiver or television setup.
NOTE: Yellow plug is for Video input, White plug is for Left Audio, and Red plug is for Right Audio.
4. Connect your iPod or iPod mini by carefully lowering it onto the iPod connector of the HomeDock so that it is resting against the Support Stand.
5. Using your HomeDock Remote Control, turn on the power to your HomeDock. Also turn on your home theater and select the correct input connection on both your stereo and TV.
6. Hit play on your HomeDock Remote and enjoy your music experience at

home. You are now ready to play your Picture Slideshows on your television as well.

Desktop PC or Mac

1. Use any standard A-to-B USB cable (not included) to connect the HomeDock base to your home computer.
2. Your iPod will now charge and sync with your computer + iTunes using the HomeDock as your desktop iPod dock.
NOTE: Your computer's powered USB port will supply enough power to operate the HomeDock and charge your iPod or iPod mini.
3. You can now control your iPod using the HomeDock Remote Control. But to hear your iPod directly, you have to connect your HomeDock audio output to your computer's audio input.

Powered Speakers


1. Plug the included AC power adapter into the back of the HomeDock base, then into any available AC power outlet.
2. Connect the included Audio cable (RCA-to-mini) to the Left and Right Outputs on the back of your HomeDock.
3. Using a mini-to-mini cable (included with most powered speakers) connect

your HomeDock to the Input on the powered speakers.

4. Connect your iPod or iPod mini by carefully lowering it onto the iPod connector of the HomeDock so that it is resting against the support stand.
5. Using your HomeDock Remote Control, turn on the power to your HomeDock.
6. Hit play on your HomeDock Remote Control and enjoy your music experience through your powered speaker system.

Playing Music

The HomeDock lets you to enjoy your iPod or iPod mini through your home stereo, powered speakers, television or computer. Here is a chart that shows you how to direct your music using the HomeDock Remote Control.



DLO HomeDock Remote Controls for Music Listening

Power	Turn on the HomeDock & iPod Turn off the HomeDock & iPod
Volume up/down	Control HomeDock volume
Play/pause	Play a song Pause a song
Next/Fast-forward	Skip to the next song Fast-forward song (press and hold)
Previous/Rewind	Play the previous song Rewind song (press and hold)
Next Playlist	Skip to the next playlist
Previous Playlist	Start a playlist over Skip to the previous playlist
Shuffle Songs	Toggles between Off, Song Shuffle and Album shuffle
Mute	Mutes the volume on your HomeDock
Repeat	Toggles between Off, Repeat a single song and Repeat all songs
Backlight	Temporarily turns the iPod backlight on

Tips & Tricks for Playing Music


After you've set up your HomeDock and connected your iPod, press the Play button on your HomeDock Remote Control and the iPod will begin playing.

To start listening to your playlists, select a Playlist using your iPod's controls. You may then scroll through the tracks on that playlist or select other playlists using the HomeDock Remote Control. You can also scroll through particular albums and artists using your HomeDock Remote Control after selecting them using your iPod's controls.

For additional tips and tricks help online at www.dlo.com/support.

The HomeDock will display your iPod photos and Slideshows on your television provided you have a compatible photo-ready iPod. To learn about your iPod's photo capabilities and how to put photos onto your iPod, you may want to visit www.apple.com/support/ipod.

You can even play music while you watch your Slideshows through your home stereo. Here is a chart that details how to control your iPod's Slideshow and Slideshow music using the HomeDock Remote Control.



DLO HomeDock Remote Controls for Photo Slideshow

Power	Turn on the HomeDock & iPod Turn off the HomeDock & iPod
Volume up/down	Control HomeDock volume
Play/pause	Pauses current Slideshow & music Resumes current Slideshow & music
Next/Fast-forward	Skip to the next photo in Slideshow
Previous/Rewind	Rewind to last photo in Slideshow
Mute	Mutes music while Slideshow continues

Tips & Tricks for Viewing Photos

You need to set up and select your Slideshow directly from the iPod. Select the Slideshow or photos folder you are interested in viewing using your iPod's controls. Once you have begun your Slideshow, your HomeDock's Remote Control can control it with the controls listed above.

NOTE: If you have questions or need help setting up your iPod for Photos and Slideshows, please visit Apple Support at www.apple.com/support/ipod.

For additional tips and tricks help online at www.dlo.com/support.

The HomeDock for iPod can also act as a desktop dock for your iPod to charge and sync your iPod to any PC or Mac. Simply connect the HomeDock to your computer via a standard A-to-B USB cable (not included) and update your iPod in iTunes by simply sliding your iPod onto your HomeDock. Your iPod will even fit onto the HomeDock without having to remove most iPod cases.

Tips & Tricks for using with Mac or PC

To enjoy your iPod's music while it is docked on your desk, either connect your HomeDock to a pair of Powered Speakers or plug it into the input of your computer to play through its speakers.

For additional tips and tricks help online at www.dlo.com/support.

Why can't I start my Slideshow using the HomeDock Remote Control?

The iPod currently requires that you select and start any Slideshow using the iPod's controls. You can control a Slideshow with your HomeDock Remote Control once it's started, but you cannot navigate and select a Slideshow from afar. To learn more about your iPod's photo capabilities, please visit the Apple website's iPod support page at www.apple.com/support/ipod.

Does the HomeDock charge my iPod's battery?

Yes. In all situations using your HomeDock, whether it's plugged into the wall via AC or plugged into your computer via USB, the HomeDock is charging the battery in your iPod so it's always fully charged and ready to go.

Do I have to use a TV with the HomeDock?

No. The only time you need a TV is to view Photos from a Photo compatible iPod. With all other uses, the HomeDock is a music-based, remote controlled home docking system for your iPod that requires nothing but a stereo or powered speakers to play your iPod's music.

Find even more help online at www.dlo.com/support.

INPUTS/OUTPUTS

Left/Right Audio: analog audio output

Video: composite video output

S-Video: separated analog video output

Power Adapter Input: 100-240VAC, 47-63 Hz

Power Adapter Output: 12VDC, 1.2 amps max

USB-A: standard universal serial bus

REMOTE CONTROL

Battery: 3V, type CR2032 or equivalent

Digital Lifestyle Outfitters Limited Manufacturer's Warranty

What This Warranty Covers. DLO (Digital Lifestyle Outfitters) warrants this product against defects in materials and workmanship. This limited warranty applies only to products manufactured by or for DLO.

What This Warranty Does Not Cover. This warranty does not apply to damage caused by: (a) accident, abuse, misuse, misapplication, ordinary wear, improper maintenance, failure to follow instructions, or products not manufactured by or for DLO; and (b) aftermarket services (including upgrades and expansions).

How Long This Warranty Lasts. This warranty lasts for a period of ninety (90) days from the date of original retail purchase.

What Digital Lifestyle Outfitters Will Do. If a defect exists, DLO will exchange the product, at its option, with a product that is new or has been manufactured from new or serviceable used parts and that is at least functionally equivalent to the original product. DLO will warrant a replacement product against defects in materials and workmanship for a period of ninety (90) days from the date of replacement.

How To Get Service. In order to be eligible for this warranty, you MUST register your purchase at www.dlo.com/register within thirty (30) days of purchasing this product. If you believe that this product is defective in materials or workmanship, please e-mail customerservice@dlo.com with a brief description of the problem, for further instructions.

No Change To Warranty. No DLO reseller, agent or employee is authorized to make any modification, extension, or addition to this warranty.

How State Law Applies. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state, or country.

Restrictions On Implied Warranties. All implied warranties, including, without limitation, warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Restrictions On Damages. DLO is not responsible for direct, special, incidental or consequential damages resulting from any breach of warranty or condition or under any other legal theory (including, without limitation, lost profits; downtime; goodwill; damage to or replacement of equipment and property; failure to maintain the confidentiality of data stored on the product; and any costs of recovering, reprogramming or reproducing any program or data stored in or used with products manufactured by or for DLO). Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

W1000-050803-A

Thanks again for your
purchase of the **DLO HomeDock**.
Where your iPod lives - at home.

